



ДШС-20КУ

NO.	DESCRIPTION	NO.	DESCRIPTION
1	LEFT SCREW	28	RIVET
2	KEYLEE CHUCK	29	PLASTIC GEAR RING
3	SCREW	30	THE FIRST PLANETARY GEAR CARRIER
4	PRESS BOARD	31	THE FIRST PLANETARY GEAR
5	TORQURE SPRING	32	INNER GEAR RING
6	TORQUE ADJUSTMENT RING	33	MOTOR GEAR
7	TORQUE ADJUSTMENT NUT	34	WASHER
8	BIG SPRING	35	SCREW
9	SPINDLE	36	PRESS BOARD
10	BEARING 6800Z	37	MOTOR
11	IMPACT BRACKET	38	INNER CABLE
12	IMPACT SPRING	39	SWITCH
13	ACTIVE IMPACT GEAR	40	DIRECTION POLE
14	QUIET IMPACT GEAR	41	LED
15	BEARING 688Z	42	SPRING
16	PIN	43	TWO SPEED CHANGE BUTTON
17	WASHER	44	SPRING
18	IMPACE/DRILL ADJUSTMENT RING	45	HOUSING
19	GEAR BOX	46	SCREW
20	LONG PIN	47	SLING
21	THE THIRD PLANET BRACKET	48	BATTERY PACK
22	GEAR RING	49	CHARGER
23	WASHER	50	DECORATION COVER
24	THE THIRD PLANETARY GEAR	888	GEAR BOX ASSEMBLY
25	THE SECOND PLANETARY GEAR CARRIER	889	MOTOR ASSEMBLY
26	THE SECOND PLANETARY GEAR		
27	TWO SPEED CHANGE GEAR RING		

DSS-20CU-EX-RUS20200717

